















E044140B



		E044140
		X1
		X1
		X1
		X5
		X3
		X4
		X4
		X1
		X4
KIT 4 pz.		X1
IT Istruzioni di montaggio GB Mounting instructions FR Instructions de montage DE Montageanweisungen ES Instrucciones de montaje		X1
IT Istruzioni di montaggio Telecomando GB Remote control mounting instructions FR Instructions de montage télécommande DE Fernsteuerung Montageanweisungen ES Instrucciones de montaje mando a distancia		-

- Tento spotřebič musí být správně nainstalován odbornou firmou v souladu s platnými zákony.
- Uspořádání přívodních kabelů a potrubí v zobrazené oblasti.
- Instalujte spotřebič podle postupu viz. obrázky.
- Případná oprava musí být provedena pouze odbornou firmou.

Výrobce odmítá jakoukoli odpovědnost v případě nedodržení výše uvedené povinnosti







Tabella di Portata (Litri/min)

Bar	Pressione Dinamica (bar) / Portata (Litri/min)									
	0,5	1	1,5	2	2,5	3	3,5	4	4,5	5
Vodopád	6,9	10,4	12,9	14,9	16,3	17,1	17,4	17,5	17,9	17,9
Sprcha	6	8,6	10,5	12,1	12,7	12,9	12,6	12,5	12,4	12,4
Mlha	3,7	4,8	5,9	6,7	7,4	8,2	8,7	9,4	9,9	10,3

MIN 1 Bar



MAX 5 Bar




BEST 3 Bar



MAX 70° C



BEST 38°/40° C

MIN 15 l/m
















Čištění



DOVOZCE

SANJET s.r.o. , nám. MUDr. J. Svobody 60 , 285 22 Zruč nad Sázavou
tel.: 327 532 298 fax: 327 532 938 mobil: 603 177 127
<http://www.sanjet.cz> , e-mail: sanjet@sanjet.cz